



Congratulations!

You have just purchased a superior window film. Many years have been devoted to the development and improvement of Sun Control Window Film so that today you may enjoy the sun without experiencing the full effects of its harmful rays.

As with all products containing an adhesive system, a drying time is necessary to achieve the proper bond to the window. During this process, some changes may be observed. So that you will understand these differences, we would like to note some of them for you:

- Drying time will be approximately 30 days.
- Please do not wash your windows during this period.
- Any haziness you may see is water under the film; you will see less and less of this as the days pass.
- A milky appearance might be experienced, but it too disappears during the drying period.
- All water bubbles will dry out, but a few small particles or points may be apparent when dry. These points, generally seen from the outside, are very tiny and are inherent in the use of a pressure sensitive adhesive system.
- You will normally see particles only if you get quite close to the glass, which is something we ordinarily do not do; they will not affect the film's performance.
- The 1/8" (3 mm) border you notice is a requirement of the application.
- Cleaning instructions are below

NOTE: Sometimes what seems to be a defect in the film is, in fact, an imperfection in the glass. It is quite natural that one should look closely at a new purchase, but at times we observe things that were always there but never noticed.

A good rule to follow is to look at the installation from six feet away. This is the manner in which we normally look through a window and the way in which you should observe your 3M™ Window Film looking through it, not at it.

CARE & CLEANING INSTRUCTIONS:

CARE MUST BE TAKEN NOT TO SCRATCH THE FILM - DO NOT USE BRISTLE BRUSHES OR ABRASIVE CLEANING MATERIALS:

1. Household window cleaning solutions like Windex or a spoon of dish soap per gallon of water works well.
2. A soft cloth or clean synthetic sponge is recommended for washing.
3. Do not use the same towel or sponge for wiping sills or frames. Paper towels or newspapers are not recommended
4. A soft squeegee is recommended for removal of cleaning solution from the film
5. Do not apply heavy pressure in any cleaning operation

TIPS:

- a) Additional caution is recommended when cleaning spliced areas.
- b) Clean in the direction of the splice
- c) Do not leave the film wet
- d) Make sure you use a different sponge, cleaning cloth and water bucket for cleaning the outside and the inside of the windows
- e) Use a little extra detergent for cleaning 3M™ Window Film - it gives more ease to squeegeeing

We hope you will enjoy your installation. With proper care, we know you will receive many years of benefit from its presence on your windows.